



合格证
Certificate

检验员 Inspector	名 称 Name	提琴节拍校音器
生产日期 Date	型 号 Model	WMT-665V

本产品经检验合格
This product is inspected and approved.



执行标准: Q/WKZDZ 005-2020
Executing standards: Q/WKZDZ 005-2020

Thank you for choosing the Cherub WMT-665V Violin Metro-tuner. Please take your time to read this Manual. We recommend keeping it for future reference.

Features

- Optimized clip for violin family.
- Metronome, Tuner and Tone Generator in one unit.
- Metronome with Tap Tempo.
- Optional Metronome sound including Mechanic, Cow Bell, Electronic, Vocal Count.
- Flexible speaker design.
- Rechargeable battery with USB-C charging port.

Product Overview



Operation Guide

POWER/PLAY Button



1. HOLD PRESS this button to turn On/Off the Power.
2. Press this button in Metronome mode to Activate/Deactivate the Metronome.
3. Press this button in Tuner mode to Activate/Deactivate the Pitch Generator.









MODE/BEAT Button



1. HOLD PRESS this button to switch Metronome/Tuner mode.
2. Press this button in Metronome mode to set Beats: 0, 1, 2, 3, 4, 5, 6, 7, 8, 9.
3. Press this button in Tuner mode to set Tuning mode:
Chro.(Chromatic) , Violin, Viola, Cello, D.B. (Double Bass).

TAP/ITEM Button



1. **HOLD PRESS** this button in Metronome mode to Activate/Deactivate Tap Tempo, and tap this button to set tempo speed.
2. Press this button in Metronome mode to select Rhythm/Sound/Volume, then adjust parameters with Select button set:
Rhythm: ♩ ♪ ♫ ♬ ♧ ♨ ♩ ♪ ♫ ♬ ♧ ♨
Sound: Mechanic , Cow Bell , Electronic , Vocal Count 
Volume: , , , 

SELECT Button



1. Adjust parameter with this set of buttons in Metronome mode (Rhythm/Sound/Volume).
2. Adjust tempo speed with this set of buttons in Metronome mode: 30bpm~250bpm.
3. Adjust reference pitch in Tuner mode with this set of buttons: 430Hz~450Hz.
4. Select Tone Generator in Tuner Mode: Chromatic (2A~6A),
Violin (4E 3A 2D 1G),
Viola (4C 3G 2D 1A),
Cello (4C 3G 2D 1A),
Double Bass (4D 3D 2A 1E).


Reset

When the product crashes, please use a paper clip to press the reset button on the back of the product to reset, as shown on the right:



Charging the device

When the battery level is low, the battery level indicator displays “”, To charge WMT-665V, connect a USB adapter (not included) to USB port using the included power cable. (See the illustration on the down.)




- To extend the battery life, please sure to get the battery fully charged before using it for the first time.
- Discharge and charge the battery completely once every three months to keep it in healthy condition.
- Make sure to disconnect the product when it's fully charged.

Precautions

- Environment
 1. Avoid using the product in high temperatures, high humidity, or sub-zero environments.
 2. Do NOT use the product in the direct sunlight.
- Please do NOT disassemble the product by yourself.
- Please keep this manual for future reference.

Specifications

Metronome

Beat	0, 1, 2, 3, 4, 5, 6, 7, 8, 9
Tempo range	30bpm~250bpm
Rhythm	
Tempo precision	±0.3%
Metronome sound	Mechanic, Cow Bell, Electronic, Vocal Count

Tuner

Tuning range	A(27.5Hz) – C(4186.0Hz)
Tuning mode	Chromatic, Violin, Viola, Cello, Double Bass
A4 range	430Hz – 450Hz
Precision	± 1Cent
Power	Built-in Rechargeable Li-Po Battery (3.7V, 150mAh) Battery Life (≈6.5 hour of tuning)
Dimensions	58mm(L)x44mm(W)x44mm(H)
Weight	40g

Accessories

- User Manual
- USB Charging Cable

* Specification may change without notice.

THE FCC REGULATION WARNING (for U.S.A.)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

© Cherub Technology Co., Ltd.

All Rights Reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Cherub Technology Co., Ltd.



www.cherubtechnology.com Made in China

